



# Assembly Instructions

Parts and Tools list


| NO. | Name             | Qty  | NO. | Name            | Qty |
|-----|------------------|------|-----|-----------------|-----|
| 1   | Support Beam     | 2    | 11  | 4mm Hex Spanner | 1   |
| 2   | Foot Pad         | 6    | 12  | 5mm Hex Spanner | 1   |
| 3   | Foot Margin      | 3    | 13  | M6*12 Screw     | 8   |
| 4   | M8*16 Screw      | 12   | 14  | M6*16 Screw     | 4   |
| 5   | Bracket          | 2    | 15  | M6*16 Screw     | 4   |
| 6   | M6*14 Screw      | 8    | 16  | Rubber Cushion  | 14  |
| 7   | Lifting System   | 1set | 17  | ST3.5*19 Screw  | 2   |
| 8   | M6*10 Screw      | 16   | 18  | ST4.8*19 Screw  | 16  |
| 9   | M8*10 Screw      | 4    |     |                 |     |
| 10  | Connection Plate | 1    |     |                 |     |




- 1 Loosen the 4 screws of beam using 4MM hex spanner, adjust the beam to proper position to fit the desktop




- 2 Attach legs to the beam using 4 of M6\*14 screws and 2 of M6\*12 screws




- 3 Attach feet to the legs using 4 of M8\*16 screws, attach the 2 of levelling foot pads to the feet by hand




- 4 Assembly another part by the same step



- 5 Attach legs to connection fittings using 4 of M6\*16 screws, attach feet to the legs using 4 of M8\*16 screws, attach the 2 of levelling foot pads to the feet by hand



- 6 Attach connection fittings to beams using 4 of M8\*10 screws



- 7 Attach brackets to beam using 4 of M6\*12 screws, and then fit the rubber cushions to the brackets and beams

